



SECURITY PRODUCTS

INSTALLATION INSTRUCTIONS

LD3012

[Model 2005-2012 Tacoma Behind Back Seat Long Gun]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the trim compartments behind the back seat of the vehicle.
3. Remove the trim compartments (both left and right) from the vehicle.
 - a. Remove the 2 bolts from the trim pieces and save for safe installment.
 - b. Once the bolts have been removed, these compartments are set in with plastic tabs that are secured to the body of the vehicle. The trims simply pop out of the vehicle.
4. Set the safe into the compartment behind the back seat.
 - a. To ensure that the safe is set properly, make sure that the factory cut holes **LINE UP** with the bolt holes from step 3.a).
5. Tighten the bolts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE SAFE OR THE VEHICLE.**
6. Enjoy your purchase!

Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH**
- 11mm Socket bit