

SECURITY PRODUCTS INSTALLATION INSTRUCTIONS LD2028CD/LD2028CDEX

[2013 to 2018 Dodge Ram 1500, 2500 & 3500 2019 1500 Classic with CD Player]

- 1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
- 2. Clear out the contents of the center console for now, including the factory mat at the bottom of the console.
- 3. Remove the padding from the bottom of the inside of the safe.
- 4. Set the safe into the center console.
- 5. Using your screwdriver or drill, place the **LOCK'ER DOWN PROVIDED** self-taping screws into their respective holes in the safe.
- 6. Tighten the screws, DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.
- 7. Re-insert the padding that was removed from the safe before installation.
- 8. Enjoy your purchase!

Tools Needed:

IMPACT DRILL or SCREWDRVIER

Contents Included: 3 8x3/4" Self-Taping Screw.



LD2028CD Install Video

