

Security Products

INSTALLATION INSTRUCTIONS

LD2046

[2012-2020 Toyota Sienna]

- For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the DOOR OPEN in order to test the lock combination effectively without locking yourself out.
- 2. Clear out the contents of the center console for now, including the factory mat at the bottom of the console.
- 3. Remove the **2 Bolts** at the bottom of the console compartment using an impact drill or socket wrench.
- 4. Place the front bracket into the front of the console first, then place the back/bottom bracket into the console, making sure that the tabs at the front of the bottom of the back bracket fit into the bottom of the front bracket.
- Secure the bottom bracket to the bottom of the console compartment using the 2 10mm BOLTS provided by LOCK'ER DOWN.
 - a. This will also secure the front bracket into place as well.
- 6. Set the **Top Assembly** onto the brackets so that the two studs in the rear of the assembly fit through the two holes in the top lip of the back bracket, and the two holes in the front of the assembly fit over the 2 studs in the top of the front bracket.
- 7. Secure the top assembly to the brackets using the 4 ACCORN NUTS provided by LOCK'ER DOWN.
- 8. Tighten the bolts and the acorn nuts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE**.
- 9. Enjoy your purchase!

Tools Needed:

- IMPACT DRILL or SOCKET WRENCH
- 10mm Socket bit and 8mm Socket Bit

Contents Included: 2 10mm Bolts.

4 Acorn Nuts

