

INSTALLATION INSTRUCTIONS

LD2055/LD2055EX

[2015-2022 Ford F150 with split bench, and 2017-2022 Ford Super Duty with split bench]

- 1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
- 2. Clear out the contents of the center console for now.
- 3. Remove the neoprene padding from the inside of the safe for now.
- 4. Set the safe into the center console.
 - a. To ensure that the safe is inserted correctly, make sure that the lock is on the forward end of the console compartment.
 - b. Once the safe is in the console compartment, pre-drill pilot holes in the same spots as the factory cut holes in the safe.
- 5. Secure the safe to the console compartment using the **SELF TAPPING SCREWS** provided by **LOCK'ER DOWN** where the pilot holes were drilled in **Step 4.b**.
- 6. Tighten the screws, DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.
- 7. Re-insert the neoprene padding that was removed from the safe before installation.
- 8. Enjoy your purchase!

Tools Needed:

- DRILL and SCREWDRIVER
- 1/8" Drill Bit

Contents Included: 4 Self-Tapping Screws

