



## INSTALLATION INSTRUCTIONS

### LD2070EX

[2018-2020 Jeep Wrangler JL (Includes Rubicon) and 2020-2021 Gladiator]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now, including the factory mat at the bottom of the console.
3. Bracket Placement:
  - a. Place the **RIGHT** and **LEFT** brackets (**see images on back for correct bracket labeling**) on the sides of the console compartment. Then slightly apply pressure against the sides.
  - b. While applying pressure, place the bottom bracket (**also labeled on the back of this page**) so that the end that comes to a point is facing **FORWARD**.
  - c. When placing the bottom plate down, make sure that the **4** slots fit over the **4** PIM studs (**2 PIM studs on both the LEFT and RIGHT-side brackets**)
  - d. Place 4 of the included **LOCK'ER DOWN** acorn nuts on each of the PIM studs (**DO NOT TIGHTEN YET**)
4. Place the top assembly, **WITH THE SAFE DOOR OPEN**, to where the **4** PIM studs line up inside the **4** slots on both the Left and Right brackets (there are **2** slots on the top of each bracket)
  - a. Screw on the remaining provided acorn nuts to **4** top assembly PIM studs from the previous step.
5. Tighten all **8** of the applied acorn nuts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE OR THE SAFE.**
6. Enjoy your purchase!

#### Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH**
- 8mm or 5/16" Socket Bit

**Contents Included:** **8** Acorn Nuts.

**LEFT, RIGHT, and BOTTOM Brackets**





Image 1: LD2070 Left Plate



Image 2: LD2070 Right Plate



Image 3: LD2070 Bottom Plate



Image 4: LD2070 Top Assembly



Image 5: LD2070 Full Assembly