



INSTALLATION INSTRUCTIONS

LD3023

[Model 2011-2019 Ford Explorer Interceptor Package]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Remove the plastic spare cover from the rear of the vehicle.
3. Set the safe into the rear of the vehicle where the spare cover was just removed.
4. Secure the safe to the vehicle using the **LOCK'ER DOWN PROVIDED CARRIAGE BOLTS AND CLAMPS**.
 - a. To secure the safe to the vehicle properly, make sure that the clamp brackets are threaded by the carriage bolts, and that the clamp brackets secure around the tubular cross braces!
5. Tighten the bolts and the acorn nuts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE**.
6. Insert the aluminum floor plate.
7. Enjoy your purchase!

Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH**
- **What is the tool that is used here!!!!!!!!!!**

Contents Included: **2** Carriage Bolts.

2 Clamp Brackets