

LOCK'ER[®] DOWN

INSTALLATION INSTRUCTIONS

LD3029EX

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now.
3. Remove the plastic lid and frame using a the **T30 and T40 TORX BITS** provided by **LOCK'ER DOWN** by removing the screws holding the top lip onto the compartment.
4. Remove the fiberglass bin from the compartment.
5. Remove the bracket from the LD3029 by unscrewing the **2 14mm** bolts (front and back of the inside of the safe) and pulling the bracket off the safe.
6. Place the bracket from **Step 5** over the opening so that the bolt holes show through.
7. Mount the frame to the compartment using the **6** bolts/screws removed in **Step 3**.
8. Set the safe into the compartment.
 - a. To ensure that the safe is insert correctly, make sure that the lock is facing the rear end of the vehicle.
9. Re-insert the **2 14mm** bolts removed from **Step 5** into their respective threads inside the safe.
10. Tighten the bolts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE COMPARTMENT.**
11. Enjoy your purchase!

Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH**
- 14mm Socket Bit

Contents Included: T30 Torx Bit
T40 Torx Bit

