

INSTALLATION INSTRUCTIONS

LD3043

[Model 2007 to 2021 Toyota Tundra Double Cab]

- 1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
- 2. Make sure that the rear seats are in the upward position.
- 3. Place the safe where the undercarriage of the rear seats is. The larger section of the safe goes on the driver's side rear.
- 4. Insert the LOCK'ER DOWN PROVIDED BOLT AND WASHER through the factory seat frame holes and through the slotted holes in the safe
- 5. Secure the bolt and washer with the LOCK'ER DOWN PROVIDED NUTS from the inside of the safe.
- 6. Tighten the nuts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE SAFE OR THE VEHICLE**.
- 7. Enjoy your purchase!

Tools Needed:

- IMPACT DRILL or SOCKET WRENCH
- 13mm Socket Bit and T25 Torx Bit

Contents Included: 2 13mm Nuts

- 2 Washers
- 2 Long Bolts

