

LOCK'ER[®] DOWN

Security Products

Installation Instructions for Model 2069 Console Safe

The Lock'er Down Model 2069 Fits the 2011 to 2017 Jeep Wrangler.

- It is a good idea to set the combination before you install the safe, and do it with the door open.
- Clear the contents out of the compartment.
- Place the left and right side plates in the console first.
- Then place the bottom plate in the bottom and connect to the side plates with the included phillips head screws.
- Place the lid assembly on top of the side plates and attach with the 4 included acorn nuts.
- Thanks and enjoy your purchase.



Lock'er Down[®] is a registered Trademark of Lock'er Down, Inc. US Reg. Number 4183198 All Rights reserved.

