



®



Security Products

INSTALLATION INSTRUCTIONS

LD2045/LD2045EX

[2015-2020 Ford F150, 2015-2022 Ford F250, F350, 2017-2022 Ford Super Duty, 2018-2019 Ford Expedition with Full Floor Console]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now
3. Place the **Top Assembly** of the console safe into the console compartment with the nose down towards the front, until it touches the bottom.
 - a. The **QR Code** at the top of the page provides a video for proper orientation into the console.
4. Adjust the top assembly so that you can pull it towards the top, and the contour of the top assembly matches that of the opening of the console compartment.
5. Hold the top assembly against the top lip of the console compartment, then place the **2** side brackets so that the bottom lip sits on the bottom lip of the console compartment, and the **2 STUDS** on either side of the top assembly fit through the holes in the side brackets.
6. Using an impact drill with a Phillips head attachment or a Phillips head screwdriver, secure the two side brackets to the bottom of the console compartment using the **4 SELF TAPPING SCREWS** provided by **LOCK'ER DOWN**.
7. Secure the brackets to the sides of the top assembly using the **4 LOCK'ER DOWN PROVIDED 13MM NUTS** onto each of the studs on the top assembly.
8. Tighten the bolts and the acorn nuts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**
9. Re-insert the padding that was removed from the safe before installation.
10. Enjoy your purchase!

Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH**
- **PHILLIPS SCREWDRIVER**
- 13mm Socket bit and Phillips Head Drill Bit (optional)

Contents Included: 4 11mm Nuts

4 Self Tapping Screws

