



INSTALLATION INSTRUCTIONS

LD2001

[VersaSafe for 2011-2019 Ford Explorer and Other Applications]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. This safe is mounted to the floor of the rear area of the vehicle using 2 brackets.
3. Attach the provided brackets to the safe using the **LOCK'ER DOWN PROVIDED WING NUTS**, making sure that the slotted holes in the bracket are centered with the holes in the safe.
 - a. The **WING NUTS** screw onto the stud in the center of the provided brackets.
4. Set the safe into the rear of the vehicle.
 - a. The safe does not have a specific slot that the safe fits into, however, **MAKE SURE TO SET IT INTO THE REAR MAKING SURE THAT THE HOLES MENTION IN STEP 3 ARE LINED UP WITH A SECTION OF THE REAR THAT CAN BE DRILLED INTO!**
5. Mark the mounting holes where you have decided to set your safe into, then remove the safe from the rear of the vehicle.
6. Remove the brackets from the safe.
7. Using the **LOCK'ER DOWN PROVIDED SELF TAPPING SCREWS**, secure the brackets to the vehicle where the mounting holes were marked in **Step 5**.
8. Set the safe back into the vehicle, making sure to line up the safe on the brackets as in **Step 3**. Then secure the safe to the brackets using the wing nuts mentioned in **Step 3**.
 - a. **DO NOT OVER TIGHTEN, THIS COULD POTENTIALLY DAMAGE THE VEHICLE OR THE SAFE.**
9. Enjoy your purchase!

Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH**
- Screwdriver

Contents Included: 2 Wing Nuts.

4 Self Taping Screws

