

LOCK'ER[®] DOWN

SECURITY PRODUCTS

INSTALLATION INSTRUCTIONS

LD2012/LD2012EX

[2005 to 2015 Toyota Tacoma]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now, including the factory mat at the bottom of the console.
3. Remove the cover from the underside of the console lid using a Phillips screwdriver to remove the **5** factory screws. Then remove the lid from the hinge by unscrewing the **4** factory bolts attached to the lid. (see back for detailed image)
4. Remove the plastic cover on both sides of console lid hinge (this can be removed with your fingernails or a flathead screwdriver) then proceed to remove the hinge by removing the factory screws used to hold it in place.
5. Remove the **2** bolts at the bottom of the console compartment (use a 10mm socket to remove these bolts)
6. Remove the padding from the bottom of the inside of the safe.
7. Set the safe into the center console.
 - a. To ensure the safe is set in the console properly, make sure that the open slots at the **BOTTOM** of the safe line up with the factory screw holes from Step 5.
8. Using your 10mm fastening device, insert the **LOCK'ER DOWN PROVIDED 10MM BOLTS** into the factory holes at the bottom of the safe (these holes should line up with the factory screw holes at the bottom of the compartment)
9. Tighten the bolts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**
10. Re-insert the padding that was removed from the safe before installation.
11. Re-apply the hinge to its original location, the plastic covering to each side of the hinge, and then re-apply the lid to the hinge and the lid undercover to the lid.
12. Enjoy your purchase!

Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH, PHILLIPS SCREWDRIVER, FLATHEAD SCREWDRIVER**
- 10mm Socket bit

Contents Included: **2** 10mm Bolts.