

LOCK'ER[®] DOWN

SECURITY PRODUCTS

INSTALLATION INSTRUCTIONS

LD2013/LD2013EX

[2007-2013 Toyota Tundra]
[2007-2022 Toyota Sequoia]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now, including the factory mat at the bottom of the console.
3. Remove the **LEFT FRONT** and **RIGHT REAR** bolts in the bottom of the center console compartment.
4. Remove the neoprene padding from the bottom of the inside of the safe.
5. Set the safe into the center console.
 - a. To ensure that the safe is set into the console properly, make sure that the two slots at the bottom of the safe **LINE UP** with the two factory bolt threads where the bolts were removed from in step 3.
6. Using your 10mm fastening device, insert the **LOCK'ER DOWN PROVIDED 10MM BOLTS** into the factory holes at the bottom of the safe (these holes should line up with the factory screw holes at the bottom of the compartment)
 - a. The **LONGER** 10mm bolt should be screwed into the right rear bolt thread, and the **SHORTER** 10mm bolt should be screwed into the left front bolt thread.
 - b. Make sure that the included washers are fit **BETWEEN** the bolts and the safe!
7. Tighten the bolts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**
8. Re-insert the neoprene padding that was removed from the safe before installation.
9. Enjoy your purchase!

Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH**
- 10mm Socket bit

Contents Included: **1 Longer** 8mm bolt with 10mm head.

1 Shorter 8mm bolt with 10mm head.

2 Washers

