

LOCK'ER[®] DOWN

SECURITY PRODUCTS

INSTALLATION INSTRUCTIONS

LD2017/LD2017EX

[2000-2007 Ford Super Duty and 2000-2005 Ford Excursion]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now, including the factory mat at the bottom of the console.
3. Remove the **4** Bolts from the bottom of the console using a Socket Wrench or Impact Drill.
4. Place the Lid Assembly into the console.
5. Hold the lid assembly against the top lip of the console and add the **FRONT VERTICAL BRACKET** along with loosely attaching the **LOCK'ER DOWN PROVIDED 13mm** bolts into the factory console screw holes from **Step 3 (DO NOT TIGHTEN YET)** (The front vertical bracket is the **SMALLER** of the two brackets)
6. Repeat **Step 5** for the **BACK VERTICAL BRACKET**.
7. Tighten the bolts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**
8. Enjoy your purchase!

Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH**
- 13mm Socket bit

Contents Included: **4** 13mm Bolts.

