

SECURITY PRODUCTS

INSTALLATION INSTRUCTIONS

LD2025/LD2025EX

[2009 to 2014 Ford F150 with Floor Console and Shifter in the Column]

- 1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
- 2. Clear out the contents of the center console for now
- 3. This safe comes fully assembled and must be disassembled before installment. To do so, remove the front and rear brackets by unscrewing the 8/32 acorn nuts using a 5/16" (or 8mm) socket wrench (keep these acorn nuts as they are needed for installment later)
- 4. Place the **TOP ASSEMBLY** onto the top lip of the console compartment as shown in the installment image.
- 5. Place the **FRONT BRACKET** over the front two studs (front bracket is the one with the gap where the trough of the top assembly would insert) and use the acorn nuts removed from step 3 to secure the bracket in place.
 - a. Make sure to squeeze the bracket towards the top assembly to ensure a secure fit!
- 6. Repeat **STEP 5** for the rear brackets, ensuring that a secure fit is achieved by squeezing the bracket towards the top assembly.
- 7. Make sure the acorn nuts are tight. **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE**.
- 8. Enjoy your purchase!

Tools Needed:

- IMPACT DRILL or SOCKET WRENCH
- 8mm Socket bit



LD2025 Install Video

