



LD2026X Install
Video

SECURITY PRODUCTS

INSTALLATION INSTRUCTIONS

LD2026X/LD2026XEX

[Late Production Model 2012 - 2014 Ford F150 with Full Floor Console and Raptor Platinum]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now.
3. Set the **LID ASSEMBLY** diagonally into the console as shown in **Figure 1** on the back.
 - a. Adjust the lid assembly while it is in the center console so that you can pull the lid assembly against the top lip of the console compartment as shown in **Figure 2**.
4. While holding the lid assembly against the top lip, place the **2 Side Brackets** on each side of the lid assembly, and secure them loosely with the **LOCK'ER DOWN PROVIDED** 13mm nuts. (See **Figure 3**)
5. Place the **2 End Brackets** into the front and rear end of the safe and secure loosely with the **LOCK'ER DOWN PROVIDED** 13mm nuts (the large "L" bracket goes in the rear of the console compartment, and the short 3" bracket attaches to the front section of the safe)
6. Place the **X Bracket** in the bottom of the console so that the factory holes in the X bracket line up with the **4 PIM Studs** located on the side brackets (two studs to each side bracket)
 - a. Apply the **LOCK'E DOWN PROVIDED** acorn nuts to the studs and secure using an 8mm socket wrench.
7. Re-insert the padding that was removed from the safe before installation.
8. Enjoy your purchase!

Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH**
- 8mm Socket Bit
- 13mm Socket bit

Contents Included: **6** 13mm Nuts.

4 Acorn Nuts.

