

LOCK'ER[®] DOWN

SECURITY PRODUCTS

INSTALLATION INSTRUCTIONS

LD2032/LD2032EX

[2021 and up Chevrolet Suburban and Tahoe, as well as the GMC Yukon]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN**
2. Clear out the contents of the center console for now, including the factory mat at the bottom of the console.
3. Remove the **2** screws at the bottom of the compartment. (These can be discarded, as they are no longer useful)
4. Remove the padding from the bottom of the inside of the safe.
5. Set the safe into the console.
6. Insert the **LOCK'ER DOWN PROVIDED BOLTS** into the holes at the bottom of the safe (these holes should line up with the factory screw holes at the bottom of the compartment)
7. Tighten the bolts.
8. Re-insert the padding that was inside the safe before installation.
9. Enjoy your purchase!

Tools Needed: **IMPACT DRILL** or **SOCKET WRENCH** with 10mm socket attachment.

Contents Included: **2** 10mm Bolts.



LD2032 Install
Video