



## Security Products

### INSTALLATION INSTRUCTIONS

#### LD2059/LD2059EX

[Armrest Safe for 2012-2022 Dodge Ram 1500,2500,and 3500]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now, including the factory mat at the bottom of the console.
3. Remove the neoprene padding from the inside of the safe for now.
4. Set the safe into the center console.
  - a. To ensure that the safe is set into the console compartment properly, make sure that that the lock is on the forward end of the console compartment.
5. Secure the safe to the console compartment using the **4 LOCK'ER DOWN** provided **SELF TAPPING SCREWS** (2 to each side of the console safe).
6. Tighten the screws, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**
7. Re-insert the padding that was removed from the safe before installation.
8. Enjoy your purchase!

#### Tools Needed:

- **IMPACT DRILL** or **SCREWDRIVER**

**Contents Included:** 4 Self Tapping Screws.

