



INSTALLATION INSTRUCTIONS

LD2069EX

[2011-2018 Jeep Wrangler JK with Coin Tray Removal]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now.
3. Place the **LEFT** and **RIGHT** plate into the console compartment (see images for description of each bracket)
4. Place the **BOTTOM** plate into the console and secure it to the **LEFT** and **RIGHT** brackets from **Step 4** using the **4 LOCK'ER DOWN PROVIDED PHILLIPS HEAD SCREWS**.
5. Secure the **LID ASSEMBLY** on the top of the **LEFT** and **RIGHT** brackets so that the studs in the lid assembly fit through the holes in the top lip of each bracket.
 - a. Secure the lid assembly to the brackets using the **4 LOCK'ER DOWN PROVIDED ACORN NUTS**.
6. Tighten the screws and the acorn nuts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE**.
7. Re-insert the padding that was removed from the safe before installation.
8. Enjoy your purchase!

Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH, SCREWDRIVER**
- 8mm Socket Bit

Contents Included: **4** Phillips Head Screws.

4 Acorn Nuts



