

# LOCK'ER<sup>®</sup> DOWN

## INSTALLATION INSTRUCTIONS

### LD2088/LD2088EX

[2021-2022 Dodge Ram TRX]



LD2088 Install  
Video

1. Take the safe apart by removing all the brackets from the safe body to install the safe.
2. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
3. Clear out the contents of the center console for now, including the factory mat at the bottom of the console.
4. Remove the factory mat from the bottom of the console compartment.
5. Insert the top plate of the safe into the console compartment with the front of the safe facing **DOWNWARD AND THE DOOR OPEN**.
  - a. It may be easier to open the door of the safe after the top plate is inside the console compartment. The door being open is necessary for installation of the brackets in the next steps.
6. Make sure the front of the safe is **FLUSH** with the front face of the console compartment (with the 12V port).
7. Insert the **SIDE BRACKETS** into the console compartment below the safe (make sure that the respective bracket is used on the driver and passenger side) so that the factory cut holes fit over the studs on either side of the top plate.
  - a. To make sure that the brackets fit in correctly, you will need to **HOLD THE SAFE UP** during the installation of the brackets.
  - b. Once the brackets have been placed over the studs on each side, **HAND TIGHTEN** the **13mm** nuts on each stud on each side.
8. Place the **REAR BRACKET** into the console compartment below the safe, so that the factory cut holes fit over the studs in the rear of the top plate.
  - a. Once the rear bracket is placed, **HAND TIGHTEN** the **13mm** nuts over the studs
9. Insert the **TOP BRACKETS** on either side of the safe, on the bottom side of the top plate.
  - a. While holding the bracket in place, **HAND TIGHTEN** the **13mm** nuts over the studs.
10. Tighten all of the previously hand tightened nuts using an **13mm Socket Wrench**. **DO NOT OVER TIGHTEN AS THIS COULD DAMAGE THE SAFE!**
11. **STARTING WITH THE REAR BRACKET**, insert the self-tapping screws into the allotted holes in each bracket (both sides and the back brackets).
12. Enjoy your purchase!

(See back for tools needed)

## Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH**
- 13mm Socket bit

**Contents Included:** 8 13mm Nuts.

6 Self Tapping Screws



Figure 1. LD2088 Assembly



Figure 2. LD2088 Bracket Diagram