



INSTALLATION INSTRUCTIONS

LD3003

[2015-2020 Escalade, Yukon, Tahoe]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Remove the plastic storage compartment behind the 3rd seat.
 - a. Remove the rubber pad in the storage compartment
 - b. Remove the **2 PLASTIC SPIN NUTS** holding the plastic compartment in the storage compartment.
3. Set the safe into the original compartment area
 - a. To ensure that the safe is sitting in the storage compartment correctly, make sure that the factory cut holes in the bottom of the safe line up with the factory bolt holes from Step 2.
4. Secure the safe to the storage compartment using the **2 Bolts** included from **LOCK'ER DOWN**.
5. Tighten the bolts and the acorn nuts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**
6. Re-insert the padding that was removed from the safe before installation.
7. Enjoy your purchase!

Tools Needed:

- **T25 TORX BIT**

Contents Included: **2** 11mm Bolts.

