

LOCK'ER[®] DOWN

INSTALLATION INSTRUCTIONS

LD3009

[Model 2021 to 2022 Chevrolet Tahoe and GMC Yukon]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Remove the plastic storage compartment in the rear of the vehicle by removing the spin nuts holding the compartment in place.
3. Insert the safe into this compartment and open the door to the safe so that the inside mounting area can be accessed.
4. Align the factory cut holes in the bottom of the safe with the studs protruding from the load floor.
5. Place the **3** enclosed brackets over the studs and secure them with the **LOCK'ER DOWN PROVIDED 1/4" NUTS**.
6. Tighten the nuts, **DO NOT OVER TIGHTEN AS THIS COULD DAMAGE THE VEHICLE OR THE SAFE!**
7. Enjoy your purchase!

Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH**
- 11mm Socket bit

Contents Included: 3 1/4" Nuts.

