



INSTALLATION INSTRUCTIONS

LD3019

[Model 2019 to 2022 Chevrolet Silverado and GMC Sierra 1500 and Model 2020 to 2022 Chevrolet Silverado and GMC Sierra 2500, 3500, and 4500 Crew and Double Cab]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. On each side of the rear seat, there is a bolt holding the seat bracket to the vehicle. Remove these bolts from each side for now.
3. Insert the mounting bracket (lower piece of bracket set) over the factory seat frame hole, then secure the bracket into place using the factory bolt removed from **Step 2**.
4. Install the cover bracket (upper piece of the bracket set) so that the tab in the front of the cover bracket secures into the slot of the mounting bracket.
5. Place the safe so that the factory cut holes fit over the 5/16" studs in the bracket, then secure to the bracket using the **LOCK'ER DOWN PROVIDED 13mm NUTS**.
6. Tighten the nuts on the inside of the safe from **Step 4**, **DO NOT OVERTIGHTEN AS THIS COULD DAMAGE THE SAFE!**
7. Enjoy your purchase!

Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH**
- 13mm Socket Bit

Contents Included: **2** 5/16" Nuts



LD3019 Install Video